

## Wii™ Controllers Sensor



### Package contents

- Wireless sensor bar for Nintendo® Wii™
- *Quick Setup Guide*


### You will need:

- 4 AAA batteries


### Features

- Receives wireless (IR) signals from wireless Wii controllers
- Extendable sensors for a wider range of play
- Sleep mode and low power indicators
- Mount on top or bottom of TV or on the wall

### Front view




### Back view




### Setting up your sensor


- 1 Remove the covers from the battery compartments on the back of the sensor bar.



- 2 Insert 2 AAA batteries into each battery compartment, then replace the covers. Make sure that the + and – symbols on the batteries line up with the + and – symbols in the battery compartment.




- 3 Mount the bar on the top (A) or the bottom (B) of the TV using the pre-attached sticker or optionally on the wall using the mounting slots over 1/4" mounting screws (not included) 48 mm apart (center to center).




- 4 Set the sensor location information in your Wii settings menu. For instructions, see your Wii's user guide.

- 5 Press **SET** on the front of the sensor bar once to have the sensor bar enter sleep mode after 1 hour of inactivity, or press **SET** twice to have it enter sleep mode after 2 hours of inactivity. The LED light above Sleep mode should light up accordingly.



- 6 When the sensor bar's batteries are low, the **STATUS** LED flashes and you should replace the batteries.



## 90-day limited warranty

Visit [www.rocketfishproducts.com](http://www.rocketfishproducts.com) for details.

Distributed by Best Buy Purchasing, LLC

7601 Penn Avenue South, Richfield, Minnesota, U.S.A. 55423-3645

© 2010 BBY Solutions, Inc.

All rights reserved. ROCKETFISH is a trademark of 2010 BBY Solutions, Inc. Registered in some countries. All other products and brand names are trademarks of their respective owners.

ENGLISH 10-0884